

POS.NO.	DESCRIPTION	SPARE PART NO.
2	Grid lid (hinge 100 mm).....	40 002
3	Mixer drum, excl. mixer gate.....	40 003
3 R	Rubber strap for grid lid.....	40 003R
4	Frame, complete w/wheels etc.....	40 004
4 A	Frame, "Body" — excl. wheels and telescopic legs.....	40 004B
5	Loading wheels (1 pc.), 80 mm, excl. bolt.....	40 005
5 B	Bolt (1 pc.) for 80 mm loading wheel.....	40 005B
6	Wheel (1 pc.), 200 mm, excl. bolt.....	40 006
6 B	Bolt (1 pc.) for 200 mm wheel.....	40 006B
6 W	Washer (1 pc.) for 200 mm wheel.....	40 006W
7	Mixer gate incl. bolt.....	40 007
8	Switch 11 Amp. w/thermal circuit breaker.....	40 008-110V
8 E	Safety switch — by the grid lid.....	40 008E
8 K	Cassette for safety switch, complete.....	40 008K
8 K1	Piece for safety switch, bended metal part.....	40 008K1
8 K2	Piece for safety switch, twisted metal part.....	40 008K2
8 K3	Piece for safety switch, rubber part.....	40 008K3
9	Mixer arm (1 pc.), Side (long).....	40 009
9 A	Mixer arm (1 pc.), Side (short).....	40 009A
10	Mixer arm (1 pc.), Side-base.....	40 010
11	Mixer arm (1 pc.), Rake.....	40 011
12	Drive shaft, complete.....	40 012
12 A	Spring pins, complete set of 4 pcs. incl. a jig.....	40 012A
13	Gear motor 0.75 kW, 30 RPM, 110V.....	40 013-110V
13 G	- Gear only.....	40 013G
13 M	- Motor only.....	40 013M-110V
14	Starting capacitor 500 µF.....	40 014_500
15	Operating capacitor 100 µF.....	40 015_100
16	Phase capacitor 20 µF.....	40 016_20
17 B	Telescopic leg (1 pc.), rear.....	40 017B
17 L	Telescopic leg (1 pc.), front — left side.....	40 017L
17 R	Telescopic leg (1 pc.), front — right side.....	40 017R
17 SB	Bolt and nut (1 set) for telescopic leg (1 pc.).....	40 017SB
19	Safety grid — by the mixer gate.....	40 019
22	Mixer arms, 4 pcs., complete set.....	40 022
22 A	Mixer arms, 4 pcs., wo/cross joint.....	40 022A
30	Discharge chute (incl. nuts).....	40 030
44	Cross joint for mixer arms, steel.....	40 044

## SPARE PART LIST - 40L, 110WV



GB-01.03.20

